


DIRECTIONS FOR USE

To have the yellowish PRP



www.seawonmt.com

SW-PRP

Autologous Platelet Rich Plasma Kit



SPECIFICATION OF CENTRIFUGE FOR SW-PRP

SW-PRP

Capacity (ml)	20 ml
Ø X L mm Dimensions	29.5 Ø X 135 mm

BUCKET

Number p.Rotor	4
Ø X L mm Dimensions	OD - 32 ID - 30 Ø X 88 mm~



33, Bucheon-ro 298beon-gil, Wonmi-gu,
Bucheon-si, Gyeonggi-do, Rep. of Korea
(Zip Code: 420-803)

TEL : +82 32 684 7071~7074
FAX : +82 32 684 7075
E-mail : seawonmt@seawonmt.com

Tecnica Scientifica Service S.r.l.

Via Bologna 220, Torino, TO, 10154, Italia
TEL : +39 011 247389
FAX : +39 011 2871735

2016.02.19 (Rev.4)



SW-PRP

Autologous Platelet Rich Plasma Kit




INDICATION



STRUCTURE OF SW-PRP

It is used for the safe and rapid preparation of autologous platelet-rich-plasma (PRP) from a small of blood at the patient's point of care.



SW-PRP – BLOOD CELL YIELDS

Group	Baseline Platelet Count $\times 10^3$ /mL(20ml)	Platelet Concentrate $\times 10^3$ /mL(2ml)	Concentration Levels (xBaseline)
Male	242	1337.25	5.52x
Female	223	1225	5.49x

ADVANTAGE OF SW-PRP



Closed structure of one tubing system


Open system should be exposed to the air during all the process. In case the air in the treatment room is not controlled and within acceptable clean level, there may be the most possibility for the contamination of PRP.

In case of our SW-PRP kit which is the closed system, although the air in the treatment room is not in acceptable clean level, it may be still safe because of no open structure.



One step Process

It is one step process to inject the extracted blood from a patient to the device



Easy Extraction of the therapeutic PRP

SW-PRP does not require a syringe with needles thanks to two built-in path ways for extraction of PRP & Plasma



DIRECTIONS FOR USE

To have Pinkish therapeutic PRP

- 01 Inject 3ml ACD-A into the Syringe
- 02 Take the cap out from the 3 way valve and it should be kept to cover the bottom of RBC Chamber
- 03 Extract 20cc of blood into the syringe (Please follow the 3 way valve direction Presented on the above image.)
- 04 Mix the blood with ACD-A in the Syringe
- 05 Slowly Inject the blood in the syringe to the device (Please follow the 3 way valve direction Presented on the above image.)

- 06 Push the cap to the bottom of RBC chamber to cover.
- 07 Centrifuge the SW-PRP under 3,850RPM at the first time during 7 minutes.
- 08 Turn the RBC chamber cap to adjust RBC level to the blue line
- 09 Centrifuge the SW-PRP under 3,850RPM at the second time during 4 minutes.
- 10 If buffy coat is below the blue line, turn the RBC chamber cap to adjust RBC level to the blue line again.

- 11 Extract all the PPP through PPP extraction port
- 12 Close PRP chamber with confirming buffy coat coming into PRP chamber
- 13 Extract the therapeutic pinkish PRP through PRP extraction port.

Remarks

Definition of Therapeutic PRP:

Therapeutic PRP should have a baseline of 1,000,000 platelets/ μ L while Normal Platelet concentration is 200,000 platelets/ μ L

If buffy coat is at the blue line, do not need to adjust the RBC chamber cap.